

E5-E6-E8-E10

COFFEE GRINDER



USER MANUAL

COMPAK

E5-E6-E8-E10

COFFEE GRINDER

1. SAFETY	4
2. DESCRIPTION	6
3. INSTRUCTIONS	6
4. IDENTIFICATION	7
5. TECHNICAL CHARACTERISTICS	7
6. EXTERNAL COMPONENTS	9
7. INSTALLATION	11
8. ADJUSTMENT	12
9. OPERATION	14
10. SETTINGS	16
11. CLEANING	25
12. MAINTENANCE	27
13. DECLARATION OF CONFORMITY	33

1. SAFETY

ADDITIONAL SAFETY MEASURES BUILT-IN TO OUR GRINDERS:

- **Special screw to keep the hopper fixed.**



This coffee grinder should only be used for the function for which it was designed: **grinding coffee beans.**



Do not use the grinder to grind other types of foods such as nuts or to grind finer granulated foods such as sugar and others.



This device **may be used by children aged 8 years and over, by people with reduced physical, sensory or mental capacities and by people without prior experience/knowledge**, provided they have received supervision or instructions on the safe use of the device and understand the associated risks.



Children should not play with the device.



Cleaning and maintenance of the device should not be carried out by children without supervision.



Do not allowing liquids to come into contact with internal or external surfaces while the appliance is on or off, except for those parts expressly mentioned in the "CLEANING" section.

If, for any reason, this happens, disconnect the power supply immediately and dry all surfaces carefully.

1. SAFETY

USERS SHOULD PAY SPECIAL ATTENTION TO, AND SCRUPULOUSLY OBEY THE FOLLOWING SAFETY INSTRUCTIONS



If it is necessary to access the interior, where the electrical components are located, **go to the nearest technical service**



In the event of any component breaking, or for any intervention we recommend contacting a technical services centre, who will carry out the repair or replacement, guaranteeing that safety standards are adhered to.



If the supplied cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



Any other use will be considered improper and dangerous.



NOTE: The manufacturer will not be liable for damage caused either by the improper use of the device or by not following the stated safety measures.

2. DESCRIPTION



Your new grinder has been designed using the most sophisticated technologies in existence. **The result is a product of high quality that offers the assurance of the best results possible.** Our products are manufactured by hand, one by one, following the strictest quality requirements. In the manufacturing process, we use only the highest quality materials (aluminum, stainless steel, etc.) especially designated for being in contact with food stuff.

For the optimum functionality of the grinder models described in this user manual, the maximum work cycles are as follows:

Model	Work cycle	
	ON	OFF
E5	7 s	60 s
E6-E8	8 s	40 s
E10	5 s	30 s

SOUND LEVEL

The level of sound emitted is:

Model	With coffee
E5	75 dB
E6-E8	70 dB
E10	68 dB

3. INSTRUCTIONS



3.1. This manual is designed to provide the necessary information to correctly install, use and maintain the grinder, as well as to highlight precautions for users to keep in mind.

To ensure the best operation of the coffee grinder, please follow the instructions as outlined in this manual.

This manual should be saved for the life of the grinder, and should always be at the disposal of the operator.

3.2. This manual uses some special terms, such as:

- **Text in bold** to highlight the importance of some terms.
- **Numbers in parentheses after a word, which match the numbering of the items** in the image to the side or in the image of the external components.

Example: (1) - 1 Hopper Lid.

Icons:

Information	Warning

4. IDENTIFICATION



The technical characteristics plate is indelibly marked with the following information:

COMPAK **CE**

Made in Spain

MODEL	SERIAL NUMBER
<input type="text"/>	<input type="text"/>
DATE	ORDER
<input type="text"/>	<input type="text"/>
ELECTRICAL DATA	
OPTIONS	OBSERVATIONS
<input type="text"/>	<input type="text"/>

COMPAK Coffee Grinders s.a Moli Barri, B, P.I. Can Barri 08-415 Bigues, Barcelona, Spain, IPX1 COFFEE GRINDER

i **NOTE: The manufacturer reserves the right to change the machine components, according to the requirements of each market, and also for technological advances.**

5. TECH. CHARACTERISTICS

5.1. SCOPE

The coffee grinders are intended for commercial applications where ground coffee must be used, or in small shops selling coffee, but not for continuous mass production of food.



This grinder should only be used to grind coffee beans.

Any other use is considered improper and dangerous.

i **NOTE: The manufacturer is not liable for damage to persons, goods, or the machine itself, if the safety regulations given in this manual are not followed, or the machine is used incorrectly.**

5.2. TECHNICAL DATA

Model		100 V 50 Hz	100 V 60 Hz	110 V 60 Hz	220 V 60 Hz	230 V 50 Hz	240 V 50 Hz	
E5	Electrical Power	480	450	550	580	550	570	W
	Spin Speed	1.360	1.670	1.690	1.650	1.370	1.385	rpm
E6 E8	Electrical Power	600	600	700	730	630	650	W
	Spin Speed	1.270	1.530	1.580	1.500	1.290	1.310	rpm
E10	Electrical Power	750	770	800	780	950	970	W
	Spin Speed	332,5	400	412,5	410	342,5	345	rpm


1. TECH. CHARACTERISTICS

Model	Ø Flat Burrs		Production 50 Hz*	Production 60 Hz*
	mm	in		
E5	58	2,3	2,5	3,1
E6	64	2,5	2,8	3,3
E8	83	3,3	4,2	4,9
E10	68 Conic	2,7	4,25	5
	mm	in	g/s	g/s


Model	Hopper capacity		Net weight		Height / Width / Depth	
	Kg	lb	Kg	lb	mm	in
E5	0,7	1,54	10,50	23,15	515 x 190 x 315	20,3 x 7,5 x 2,4
E6	1,25	3,08	13,20	29,10	600 x 230 x 385	23,6 x 9,05 x 15,15
E8			15,36	33,86		
E10	1,25	3,08	19,50	42,99	660 x 230 x 385	25,98 x 9,05 x 15,15
	Kg	lb	Kg	lb	mm	in

* Production and durability based on a medium roast coffee and grinding point for Espresso.
There is a direct relation between the wear of the burrs and the increase in time per dose

6. EXTERNAL COMPONENTS E5



6. EXTERNAL COMPONENTS E6-E8-E10-PKE



E6-E8-E10

7. INSTALLATION

7.1. LEGAL NOTICES

 The installer must read this instruction manual carefully before installing the machine.



The installation of the device must be carried out by qualified and authorised personnel, obeying all the current safety and hygiene regulations.

7.2. IMPORTANT WARNINGS

 The operator must be a responsible adult. Never a child nor someone without the ability to accept that responsibility.

When handling the grinder, the following precautions should be obeyed:

- When removing the grinder from the packaging, always pull it by the handles of the bag.
- Feet must not be bare.
- Hands and feet must be dry.
- Do not get the machine wet.
- Do not expose the machine to direct sunlight or other atmospheric agents.
- Never insert any object into the coffee inlet or outlet while the appliance is running. (Please remember that when the grinder stops, the burrs will keep turning for a short while).
- When unplugging the grinder, always pull on the plug and never the power cable to avoid a possible short circuit.
- Care is needed when handling cutting burrs during cleaning.

 **NOTE:** This coffee grinder should not be installed in places (SUCH AS INDUSTRIAL KITCHENS) where are expected to be cleaned using water jets or a steam cleaner.

7.3. WHERE TO USE IT

 The appliance must be installed on a solid and flat surface.



The minimum size for the working space, to ensure you get the best performance from the machine, must be the following:

Model	E5	E6/E8	E10	
Height	535	620	680	mm
	21	26,8	26,8	in
Width	210	250	250	mm
	8,3	9,8	9,8	in
Depth	335	405	405	mm
	13,2	16	16	in

- Install the grinders on tables that are completely level and in areas free from external vibrations
- Install the grinders in an area where there are installations with a ground connection.
- Avoid places where abrupt changes in temperature, humidity or airflow may occur.

7.4. INSTALLING THE COFFEE GRINDER

Before connecting the coffee grinder, check the following:

- The characteristics on the data plate must match those of the electrical mains network.
- The electrical connection plug matches the socket into which it is to be plugged.
- Ensure that the electrical power of the facility is adequate for the power consumed by the appliance.
- The point of connection to the electrical mains network must be protected with the appropriate electrical protection device.
- The equipment must be correctly connected to a ground connection according to the current safety regulations.

8. ADJUSTMENT

8.1. GRINDER SET UP

Place the hopper (2) on the grind regulator (8) and make sure the bean trap (4) is in the closed position (Fig. 1).




Fig. 1

Lock the hopper (2) in place using a Phillips head screw driver to gently tighten the hopper security screw making it match to the hole at the bean hopper collar (3) (Fig. 2).




Fig. 2

Remove the hopper lid (1), fill the hopper with coffee (2), and replace the lid on the hopper (1) (Fig. 3).



Fig. 3

Plug in the grinder, and press the main power switch (13) to ON position, and open the bean trap (4) to allow coffee to pass into the grind chamber (Fig. 4).



Fig. 4

8. ADJUSTMENT

8.2. ADJUSTING THE LOWER PORTAFILTER SUPPORT

In order to ensure the proper distribution of ground coffee in the portafilter, while supporting the portafilter in a hands-free position during dosing, it is possible to adjust the height of the lower portafilter support (9), also adjust forward and backwards the position of the portafilter respect the coffee exit chute.

To do this adjustment operation:

1. Loosen the screw (15) on the lower support (9) by using the #3 Hex Allen key included with your grinder.
2. Adjust the support to the desired height using the portafilter as the point of reference.
3. Tighten the screw (15) with the #3 Hex Allen key provided (Fig. 5).




Fig. 5

4. With the #3 Hex Allen key provided tighten or untighten the screw located in front of the portafilter (17) to find the right spot.




Fig. 6

Fig. 7

8.3. GRIND ADJUSTMENT SYSTEM

Rotate the grind regulator (8) until reaching the grind level desired.

Rotating the grind regulator clockwise will result in a coarser grind; turning the regulator counterclockwise will result in a finer grind (Fig. 8).



Fig. 8

Once you reach the desired grinding point, you can lock the grinding regulator using the regulator brake. (7) (Fig. 9).




Fig. 9

8. ADJUSTMENT

NOTE: It is recommended that this operation be performed, when changing to a finer grinding, with the motor running, to prevent coffee from building up between the burrs and blocking the grinder.

NOTE: If the coffee throughput is very low, this is because the coffee is being ground very fine. If the throughput is very high, this is because the coffee is being ground very coarse. A perfect Espresso is produced when the grinding gives an infusion of 25 ml of coffee in 25 seconds using about 7 g of ground coffee.

8.4. PREPARATION OF THE PORTAFILTER DETECTOR (OPTIONAL)

1. Place the detector on the double portafilter (Fig. 1).
2. Check that the detector ring tab is properly closed (Fig. 2).
3. Make sure that the arrow is in the correct position on the lower side (Fig. 3).




Fig. 1

Fig. 2

Fig. 3

9. OPERATION

9.1. MAIN SWITCH

The main switch (13) has the following positions: **AUTOMATIC / OFF / MANUAL** or **ON / OFF**.

	E5	E6-E8 E10
The equipment's electronic functions are activated	I	ON
Equipment off	O	OFF
Equipment in manual mode.	II	



9.2. USAGE

Through the program menu (section 10.4.3), it is possible to select three distinct functional modes: **PUSH, DETECTION** and **TOUCH**.

9.3. PUSH MODE

In the **PUSH** mode, a pre-programmed single, double or triple dose can be set by simple pressing the corresponding icon on the TFT screen (14).

The preselection of a single, double or triple dose will remain active until it is changed by pressing one of the three numbered icons. This preselection is reflected on the TFT screen (14) with the icon of the active selection in the secondary color, and the rest of the icons in the main color.

Dispensing the preselected dose by pressing the lower pulse button (11) one time. When the grinding cycle begins, a timer countdown will begin on the TFT screen (14), which will count down the timed dose cycle to zero.

9. OPERATION

Once the grind cycle is initiated, it can be paused by pressing the lower activation button (11).

The cycle will pause, and will complete the timed grind cycle if the lower activation button is pressed again within 10 seconds. After 10 seconds of inactivity, the grind cycle will reset to the complete cycle time.

Grind pause can be activated or deactivated by pressing the lower pulse button (11). First, set up by following these steps: **MENU / SETTINGS / GRIND PAUSE.**

9.4. TOUCH MODE

In this mode of operation when making the selection of single, double or triple doses of coffee by pressing the appropriate numeric TFT icon screen (14) starts grinding the selected dose without the need to actuate the lower dose button (14).

The time set for that dose will decrease to zero, at which point the dose ends.

Once the cycle starts grinding using the lower dose button (11) and is pressed again, the grinding cycle will stop. If within 10 seconds it is pressed again, it will complete the remaining time of the original dose time setting. After 10 seconds of inactivity the grinder will return to standby mode.

To pause by pressing the lower activation button (11), you can enable or disable, accessing **MENU / SETTINGS / GRIND PAUSE.**

Pause grinding may also be performed by pressing the active icon on the TFT display (14). This pause cannot be enabled or disabled via the **MENU.**

9.5. DETECTION MODE

In this operating mode, the grinder detects the presence of the portafilter through the movement of a fitted Tag. When the portafilter with the mounted Tag comes within range, the system identifies it and automatically grinds DOSE 2 by pressing the lower portafilter button (11) once.

Once Dose 2 is detected, you have 5 seconds to press the lower button (11). If you want to cancel the selection, you can press 1 on the TFT screen (14). If after 5 seconds, the lower button is not pressed (11), the grinder will return to the standby mode.

9.6. TAMPER

9.6.1. Fixed Tamper (Optional)

Position the portafilter below the tamper and push up to tamp the ground coffee (Fig. 4).



Fig. 4

10. SETTINGS

10.1. DISPLAY ICON GUIDE





* In the case of 3 dose activation

10.2. GRIND TIME CONFIGURATIONS

10.2.1. The grinding times can be configured for automatic, preselection and instantaneous operation modes, and when modified in one of the three modes they are updated for all modes simultaneously.


To modify 1 dose, push the Coffee Bean icon  of the Home menu and the dose time menu will be accessed.

10.2.2. Within the dose time menu you can choose to change the time of 1, 2 or 3 doses (if it is active), by pressing the symbol > that is in each of them, thus going to the dose time configuration menu. To access dose 3, you must scroll down so that the option appears.




10. SETTINGS

10.2.3. Inside the dose time configuration menu, this can be changed by sliding the seconds and tenths of a second up or down until the desired time is obtained and press **OK**.




10.2.4. When accepting, it will return to the previous menu to be able to continue changing more dose times or if the button  is pressed it will return to the Home screen.





10.3. ACCESS TO THE CONFIGURATION MENU

10.3.1. Press 



10.3.2. There are 5 options, use the horizontal scroll to navigate between: **Mode**, **Statistics**, **Recipes** and **Settings**.




10. SETTINGS

10.4. MODE MENU

10.4.1. Press  in the configuration Menu.




10.4.2 There are three different options to operate the grinder, **Push**, **Detection** or **Touch**. Choose between the different working modes by pressing the button .




10.5. STATISTICS

10.5.1. Press .




10.5.2. The number of independent doses for each selection is shown, either absolute which is from the date of installation of the grinder, or relative from a counter reset date. Burrs wear can also be checked here.



10. SETTINGS

10.5.3. Relative Statistics can be reset by pressing the Reset Relative button and then entering the Password.




10.5.4. To access the Burrs wear graph, press 



10.5.5. There is a graphical view of the Burrs wear in % as well as the Total ground Kg and the Kg configured for the Burrs change notice.

Model	KG*	KG Red Speed*
E5	400	-
E6	600	2.250
E8	800	5.000
E10	1.200	8.000

* Production and durability based on a medium roast coffee and grinding point for Espresso. There is a direct relation between the wear of the burrs and the increase in time per dose




10.6. RECIPES

10.6.1. Press 



10.6.2 There are two options, the first one will access the menu to configure the dose times, the second will activate or deactivate the Grinding Pause (by default it is active).


10. SETTINGS





If accessing the menu to configure dose times, please follow the steps in point 10.2.2. You will be able to activate or deactivate the grinding pause by pressing the button , if the grinding pause is active, or  if it is deactivated.

10.7. SETTINGS MENU

10.7.1. Press  in the configuration menu.




There are 6 Settings options. Use the horizontal scroll to navigate between: **Password, Language, Screensaver, Sounds, Dose Alarm, and Date / Hour.**




10.8. PASSWORD

10.8.1. Press .




10. SETTINGS


If the Password is active, enter the Default one: 0000



10.8.2. Activate or deactivate the Password by pressing . To modify the Password press 




10.8.3. Enter a new 4 numbers Password. Show or hide the numbers by pressing  or delete the numbers pressing 




10.9. LANGUAGE

10.9.1. Press 




10.9.2. Choose between the different languages available using the vertical scroll.




10. SETTINGS

10.10. SCREENSAVER


10.10.1. Press 



10.10.2. Activate or deactivate the Screensaver by pressing . To modify the activation time press 




10.10.3. Change the minutes by sliding up or down and press the button **OK** to confirm.




10.11. SOUNDS

10.11.1. Press 




10.11.2. Activate or deactivate the sound by pressing the button 



10.12. BURRS CHANGE ALARM

10.12.1. Press 



10.12.2. Activate or deactivate the Burrs change alarm by pressing , adjust the Weight of the Dose 2, the Burrs change alarm Kg or Reset Alarm.

10. SETTINGS




10.12.3. To set the Weight of Dose 2 press >




10.12.4. Change the grams of Dose 2 by sliding the grams or tenths of a gram up or down until the desired weight is reached and press the button **OK** to accept.

Dose 2 will be the average weight used to determine burr wear.




10.12.5. To delete the stored data of the Burr change alarm, i.e. once replaced the current set of Burrs, scroll vertically, press the Reset Alarm button and then enter the Password.




10.13. DATE/HOUR

10.13.1. Press 




10. SETTINGS


10.13.2. Edit both the time, the date, or the way to show the date between DD/MM/YY or MM/DD/YY.



10.13.3. Edit the time by pressing > to access the time setting screen. Change the hours, minutes, and seconds by sliding up or down until the desired time is obtained and press the button **OK** to confirm.



10.13.4. Edit the date by pressing > to access the date setting screen. Change the days, months, and years by sliding up or down until the desired time is obtained and press the button **OK** to confirm.



11. CLEANING

11.1. GENERAL CLEANING

11.1.1. To ensure that the grinder functions properly, and produces the highest quality grind possible, the parts that come into contact with coffee should be cleaned periodically.

General Cleaning guidelines as follows:

- Always turn the main power switch to the off position (13).
- Unplug the machine from the power source.
- Do not submerge the grinder in water or use power washing devices.
- The appliance is not to be cleaned with a water jet.

11.2. BEAN HOPPER CLEANING

11.2.1. In order to properly clean the bean hopper (2), first empty out all remaining beans and fragments.

To remove the hopper, first close the bean trap (4), and then loosen the hopper lock screw (3) and lift the hopper straight up.

Clean the hopper (2) with a moist soft cloth or with a small amount of water and neutral soap to eliminate any oily residue from the beans.

Replace the bean hopper (2) following the same steps as the removal process, but in reverse.

11.3. CLEANING THE COFFEE EXIT CHUTE

11.3.1. It is very important to maintain the exit chute (12) clean of coffee in order to assure the consistency of the dose and the continued functioning of the grinder.

The dose activation button (11) along with the portafilter holders should be wiped periodically to prevent buildup of coffee grounds and oils.

In order to clean the coffee outlet in **E6** and **E8** models, use the #3 Hex Allen key supplied to loosen the screw that holds the nozzle and thus be able to remove and clean it.



11.3.2. For the **E10**, to properly disassemble the regulator, please follow the steps outlined in section **12.3.7.** for standard grinders or section **12.3.10.** for grinders equipped with the **Lock Load System**. Use the #3 Hex Allen key supplied to loosen the screw that holds the nozzle located on top of the grinding cavity, according to **(Fig. 1)**, and remove it by pulling downwards, as shown in **(Fig. 2)**.




Fig. 10

Fig. 11

11. CLEANING

11.4. CLEANING THE GRIND CHAMBER

It is recommended to clean the grind chamber monthly using a cleaner. This process helps eliminate any smelly residues from the coffee remnants, which can have a negative impact on the quality of the brewed coffee.

Please exercise caution when handling the cutting burrs during the cleaning process.

The steps to follow are:

- In order to properly clean the bean hopper (2), first empty out all remaining beans and fragments.
- Close the bean trap on the hopper (4) and grind out the remaining coffee in the grind chamber.
- Pour the recommended grinder cleaning product into the bean hopper (2) and open the bean trap (4), allowing the cleaning product to pass into the grind chamber.
- Grind the cleaning product at a medium coarse grind setting until the recommended amount is passed through the system and nothing remains in the grind chamber.
- Clean the hopper (2) and refill with coffee beans.
- Discard the first 2-3 doses of coffee to assure that the residual cleaning product is removed from the grind chamber and set the grind regulator to the desired setting (8).
- Following these steps will ensure that the grinder is clean and ready for use.
- We do not recommend the taking apart of the grind assembly unless changing burrs, or removing a blockage/obstruction

in the grind chamber. Removal of the grind assembly should be performed by a qualified service technician.

11.5. CLEANING THE OUTSIDE OF THE GRINDER

To clean the exterior of the grinder, first wipe with a dry soft cloth, and then gently wipe with a damp cloth and neutral soap.

11.6. CLEANING THE TOUCH SCREEN

Proper cleaning should be done with a soft, damp microfiber towel. Preferably distilled water or other cleaning product specifically designed for touch screen cleaning.

Turn off the grinder and gently wipe off the screen using a circular motion.

12. MAINTENANCE

12.1. GENERAL WARNING

Before performing any type of maintenance, you should:

- Always turn **OFF** the main power switch to the off position (13).
- If the grinder is jammed, unplug it from the power source and contact an authorized service technician.

In case of breakdown or malfunction, turn off the appliance, we should never try to repair it, it is essential to call the nearest technical service.

⚠ NOTE: Not following these warnings can compromise the safety of the grinder as well as the user.

12.2. GENERAL MAINTENANCE OF THE GRIND CHAMBER

To guarantee the efficiency and correct operation of the grinder, it is essential to follow manufacturer instructions and ensure that all maintenance work is carried out by qualified staff.

Dull burrs will result in; a lower quality grind, greater heat generation in the coffee and grinder, increased electrical consumption, and finally it puts additional stress on the grinder motor.

⚠ Not following the recommended burr life guidelines can compromise the safety of the grinder.

These operation should be done by a qualified service technician wearing safety gloves.

12.3. GRINDING GROUP MAINTENANCE

To perform grind chamber maintenance please observe the following steps:

12.3.1. Turn off the grinder by making sure the main power switch (13) is on the **OFF** position. Disconnect the plug from the power source. Loosen the hopper security screw (3) using a Phillips head screw driver as seen in (Fig. 1).



Fig. 1

12.3.2. Check that the shutter is in the closed position before removing the hopper from the grind regulator (8) (Fig. 2).




Fig. 2

12. MAINTENANCE

From that point, if your grinder is an **E5** keep following the next steps until **12.3.5**. if not skip until the point **12.3.6**.

12.3.3. To avoid losing the position of the regulator scale with respect to the current grinding point, it is essential to tighten the setting of the grinding regulator using the adjusting brake (7) by turning it clockwise (**Fig. 3**).




Fig. 3

12.3.4. Loosen the grinding regulator screws using a #3 Hex Allen key, according to (**Fig.4**). Remove the regulator by pulling up. (**Fig.5**).




Fig. 4

Fig. 5

12.3.5. Loosen the upper burrs support screws using a #3 Hex Allen key, according to (**Fig.6**). Remove the upper holder by pulling upwards to access the grinding cavity, clean the interior with the help of a brush

or vacuum cleaner and remove any coffee residue from the grinding cavity (**Fig.7**).




Fig. 6

Fig. 7

12.3.6. From this point, if your grinder has **Lock Load System** skip until the point **12.3.11**. if not, keep following the next steps. To avoid losing the position of the regulator scale with respect to the current grinding point, it is essential to tighten the setting of the grinding regulator using the adjusting brake (7) by turning it clockwise (**Fig. 8**). Remove the screw with a #2 Hex Allen key located in the adjusting brake (7). (**Fig. 9**).




Fig. 8

Fig. 9

12.3.7. Remove the regulation brake by pulling upwards (7) (**Fig. 10**). Loosen the grinding regulator screws using a #3 Hex Allen key, according to (**Fig. 11**).

12. MAINTENANCE




Fig. 10

Fig. 11

12.3.8. Remove the regulator by pulling upwards (Fig. 11). Loosen the upper burrs support screws with a #3 Hex Allen key, according to (Fig. 12).




Fig. 11

Fig. 12

12.3.9. Remove the upper holder by pulling upwards to access the grinding cavity, clean the interior with the help of a brush or vacuum cleaner and remove any coffee residue from the grinding cavity (Fig. 13).

When reassembling, proceed by reversing the disassembling steps and to align the regulator hole to the regulator brake post according to (Fig. 14).




Fig. 13

Fig. 14

Only for grinders with a Lock Load System

12.3.10. To avoid losing the position of the regulator scale with respect to the current grinding point, it is essential to tighten the setting of the grinding regulator using the adjusting brake by turning it clockwise (Fig. 15).




Fig. 15

12.3.11. To access the grinding cavity, insert the tools into the hexagonal holes located on the Lock Load System (10) according to (Fig. 16). Turn both tools in the direction shown by the icons or according to (Fig. 17).



Fig. 16

Fig. 17

12. MAINTENANCE

12.3.12. Pull up holding the grind regulator (16), to access the grinding cavity, clean the interior with the help of a brush or vacuum cleaner and remove any coffee residue from the grinding cavity (Fig. 18).




Fig. 18

12.3.13. When reassembling the grind regulator, face the silicon curtain in front and the three holes with three pins in the grind chamber (Fig. 19).




Fig. 19

12.3.14. When the grinding regulator is in place, lock the system by turning both tools (40) in the direction shown by the icons or according to (Fig. 20) until they are in the working position.



Fig. 20

12.4. REPLACING THE CURTAIN OR METAL COMB

The curtain or metal grid ensures consistency in the dosage and reduces static electricity.

Depending on the model, our **On-Demand** grinders have different methods for replacing the curtain/metal grid. The **E6**, **E8**, are replaced using the instruction from **12.4.4.**, while **E10** is replaced using the instructions from **12.4.8.**

12.4.1. In **E5** is located between the coffee exit chute and the grinder's body, can be replaced after removing the regulator from the grinder, following the instructions up to step **12.3.5.** To remove it, use a Phillips head screw driver to loosen the two top screws (Fig. 21). And the screw located beneath the coffee exit chute with #3 Hex Allen key (Fig. 22).



Fig. 21

Fig. 22

12.4.2. Partially move the TFT plastic cover forward (Fig. 23). And then downward along the coffee exit chute until it can be completely freed (Fig. 24).




Fig. 23

Fig. 24

12. MAINTENANCE

12.4.3. Using a #3 Hex Allen key, loosen the two screws of the coffee exit chute and remove it from the grinder body to gain access to the metal (**Fig. 25**).



Fig. 25

If your grinder doesn't have **Lock Load System** keep following next steps if not skip to **12.4.5**.

12.4.4. After the point **12.3.7**, use a #3 Hex Allen key to untighten the screw that holds the curtain, and pull up to release (**Fig. 26**).



Fig. 26

12.4.5. After the point **12.3.12**, use a #3 Hex Allen key to untighten the 3 screws that holds the regulator (8) to the top burrs support (**Fig. 27**). Pull up the regulator from the top burrs support (**Fig. 28**).




Fig. 27

Fig. 28

12.4.6. Use a #3 Hex Allen key to untighten the screw that holds the curtain, and pull up to release (**Fig. 29**).




Fig. 16

12. MAINTENANCE

12.5. BATTERY REPLACEMENT

All models have a built-in battery backup to save operating information when the grinder is shut down. When this battery is depleted, it must be replaced with another of the same characteristics: CR2032 (3V Lithium Cell). The battery should be changed when the grinder no longer maintains dose times.

The procedure for replacing the battery without losing the operational data stored in the grinder is as follows:

- Remove the exit chute (12) as shown in section 11.3.1. Also, remove the grind regulator (8) by performing the same operations described in sections 12.3.9 or 12.3.6, depending on whether the grinder uses the Lock Load System or not.
- Turn with a #3 Hex Allen key just 360° counterclockwise (Fig. 23). Remove with a #3 Hex Allen key the screw in the bottom of the plastic cover (Fig. 24).




Fig. 23

Fig. 24

- Pull the display cover and unclip the cables from the PCB (Fig. 25) loosen the last screw T20 Torx and pull to remove it (Fig. 26).




Fig. 25

Fig. 26

- Remove the battery from its holder inside the control panel and replace it with a new one (Fig. 27).




Fig. 27

13. DECLARATION OF CONFORMITY

In accordance with European community directives, quality certificates have been applied. All materials have been adapted and technical reports are available at our offices.

2014/30/UE on the approximation of the laws of the Member States relating to electromagnetic compatibility.

06/42/EC amending Directive 95/16/EC on the approximation of the laws of the Member States relating to machinery

REG. 1935/2004 amending Directive 89/109/EC on the approximation of the laws of the Member States relating to material and objects destined to make contact with nutritional products.

03/108/EC amending Directive 2002/96/EC on waste electrical and electronic equipment (WEEE).

2014/34/UE on the harmonization of the laws of Member States relating to electrical equipment designed for use within certain voltage limits.

2012/19/UE of 04/07/2012 on the approximation of the laws of the Member States on waste electrical and electronic equipment (WEEE).

11/65/EU related to the restriction on the usage of certain dangerous substances with electrical equipment and electronics.

Environment

Do not throw the appliance away with the normal household waste; hand it in at an official recycling collection point. By doing this, you will help to preserve the environment.

The Legal Representative

Jesús Ascaso



Compak Coffee Grinders, s.a.

Molí Barri, Parcela B - Pol. Ind. Can Barri - 08415 Bigues i Riells - Barcelona - Spain
Ph. 34 93 703 13 00 - www.compak.es - info@compak.es



USER MANUAL

K09657H02 | PROC-CAL/002/03 USER MANUAL | V. 11/07/2023